



REAL TIME CALENDAR

Configures charging profile depending on time/date



AIR PUMP

Recharges batteries with air circulation option (available only for GREEN6)



EXTERNAL CHARGER LAMP

Bright external lamp for easy charging status signaling



ANTISPARK

Automatic power interruption for safe plugs disconnection (extra plug wiring requested)



NTC TEMPERATURE SENSOR

Temperature monitor for optimal charging process



ETHERNET INTERFACE

Remote charger monitor via web server



WiFi INTERFACE

Wireless remote charger monitor via web server



2G/3G DATA CARD

2G/3G data card for remote charger monitor via web server



DIGITAL I/O

Digital input/output signals for charger interface to complex systems



HFView SOFTWARE

Through HFView software, connecting PC and charger with USB cable, allows access to several options:

- Monitor and download charging cycles
- Modify charger configuration of voltage, current profile
- Enable charger options
- Design/modify charging profiles